

© Copyright SEK Svensk Elstandard. Reproduction in any form without permission is prohibited.

Railway applications – Communication, signalling and processing systems – European Rail Traffic Management System – Part 2: Ergonomic arrangements of GSM-R information

(CENELEC Technical Specification 50459-2:2021)

Nationellt förord

En teknisk specifikation, TS, utarbetad inom CENELEC är avsedd att ge beskrivningar som kan stödja den inre marknadens utveckling, ge vägledning beträffande specifikationer eller provningsmetoder eller ge specifikationer för teknikområden under snabb utveckling. Ett förslag till europeisk standard, EN, som det inte varit möjligt att nå tillräcklig enighet kring, kan också fastställas som TS, för att användas på försök (som förstandard) och för att efter eventuella justeringar eller bearbetningar senare fastställas som EN. En teknisk specifikation har en giltighetstid som är begränsad till tre år, med möjlighet till förlängning med tre eller högst sex år.

Tidigare fastställd SEK TS 50459-2, utgåva 2, 2018, gäller ej fr o m 2021-04-21.

ICS 03.220.30; 13.180.00; 35.240.60

Detta dokument är fastställt av SEK Svensk Elstandard, som också kan lämna upplysningar om **sakinnehållet**.
Postadress: Box 1284, 164 29 KISTA
Telefon: 08 - 444 14 00.
E-post: sek@elstandard.se. Internet: www.elstandard.se

Standarder underlättar utvecklingen och höjer elsäkerheten

Det finns många fördelar med att ha gemensamma tekniska regler för bl a mätning, säkerhet och provning och för utförande, skötsel och dokumentation av elprodukter och elanläggningar.

Genom att utforma sådana standarder blir säkerhetsfordringar tydliga och utvecklingskostnaderna rimliga samtidigt som marknadens acceptans för produkten eller tjänsten ökar.

Många standarder inom elområdet beskriver tekniska lösningar och metoder som åstadkommer den elsäkerhet som föreskrivs av svenska myndigheter och av EU.

SEK är Sveriges röst i standardiseringsarbetet inom elområdet

SEK Svensk Elstandard svarar för standardiseringen inom elområdet i Sverige och samordnar svensk medverkan i internationell och europeisk standardisering. SEK är en ideell organisation med frivilligt deltagande från svenska myndigheter, företag och organisationer som vill medverka till och påverka utformningen av tekniska regler inom elektrotekniken.

SEK samordnar svenska intressenters medverkan i SEKs tekniska kommittéer och stödjer svenska experters medverkan i internationella och europeiska projekt.

Stora delar av arbetet sker internationellt

Utformningen av standarder sker i allt väsentligt i internationellt och europeiskt samarbete. SEK är svensk nationalkommitté av International Electrotechnical Commission (IEC) och Comité Européen de Normalisation Electrotechnique (CENELEC).

Standardiseringsarbetet inom SEK är organiserat i referensgrupper bestående av ett antal tekniska kommittéer som speglar hur arbetet inom IEC och CENELEC är organiserat.

Arbetet i de tekniska kommittéerna är öppet för alla svenska organisationer, företag, institutioner, myndigheter och statliga verk. Den årliga avgiften för deltagandet och intäkter från försäljning finansierar SEKs standardiseringsverksamhet och medlemsavgift till IEC och CENELEC.

Var med och påverka!

Den som deltar i SEKs tekniska kommittéarbete har möjlighet att påverka framtida standarder och får tidig tillgång till information och dokumentation om utvecklingen inom sitt teknikområde. Arbetet och kontakterna med kollegor, kunder och konkurrenter kan gynnsamt påverka enskilda företags affärsutveckling och bidrar till deltagarnas egen kompetensutveckling.

Du som vill dra nytta av dessa möjligheter är välkommen att kontakta SEKs kansli för mer information.

SEK Svensk Elstandard

Box 1284
164 29 Kista
Tel 08-444 14 00
www.elstandard.se

English Version

**Railway applications - Communication, signalling and processing
systems - European Rail Traffic Management System - Part 2:
Ergonomic arrangements of GSM-R information**

Applications ferroviaires - Systèmes de signalisation, de
télécommunications et de traitement - Système européen
de gestion du trafic ferroviaire - Interface de conduite -
Partie 2: Aménagement ergonomique des informations
GSM-R

Bahnanwendungen - Telekommunikationstechnik,
Signaltechnik und Datenverarbeitungssysteme -
Europäisches Leitsystem für den Schienenverkehr - Teil 2:
Ergonomische Anordnung der GSM-R Informationen

This Technical Specification was approved by CENELEC on 2021-02-08.

CENELEC members are required to announce the existence of this TS in the same way as for an EN and to make the TS available promptly at national level in an appropriate form. It is permissible to keep conflicting national standards in force.

CENELEC members are the national electrotechnical committees of Austria, Belgium, Bulgaria, Croatia, Cyprus, the Czech Republic, Denmark, Estonia, Finland, France, Germany, Greece, Hungary, Iceland, Ireland, Italy, Latvia, Lithuania, Luxembourg, Malta, the Netherlands, Norway, Poland, Portugal, Republic of North Macedonia, Romania, Serbia, Slovakia, Slovenia, Spain, Sweden, Switzerland, Turkey and the United Kingdom.



European Committee for Electrotechnical Standardization
Comité Européen de Normalisation Electrotechnique
Europäisches Komitee für Elektrotechnische Normung

CEN-CENELEC Management Centre: Rue de la Science 23, B-1040 Brussels

Contents	Page
European foreword.....	6
Introduction.....	7
1 Scope.....	8
2 Normative references.....	8
3 Terms, definitions and abbreviated terms.....	8
3.1 Terms and definitions.....	8
3.2 Abbreviated terms.....	11
4 General DMI-related principles.....	12
4.1 General ergonomic principles.....	12
4.2 Hardware.....	12
4.3 Areas on the DMI.....	12
4.4 Colours.....	16
4.5 Information.....	16
4.6 Flashing.....	22
4.7 Sounds.....	22
4.8 Lists.....	22
5 GSM-R functions shown on the DMI.....	23
5.1 Introduction.....	23
5.2 General functions.....	23
5.3 Registration functions.....	45
5.4 Network selection.....	49
5.5 Call-related functions: incoming non-emergency.....	50
5.6 Call-related functions: outgoing non-emergency.....	53
5.7 Call-related functions: incoming emergency.....	58
5.8 Call-related functions: outgoing emergency.....	59
5.9 Supplementary Services.....	61
5.10 Other calls.....	69
5.11 Select a called party.....	75
5.12 Use of in-call menu.....	80
5.13 Loss of network.....	80
5.14 Shunting.....	81
5.15 Direct mode.....	85
5.16 Text messaging.....	85
6 Sounds.....	86
6.1 General.....	86
6.2 Incoming calls (R1, R2, R3).....	87
6.3 Outgoing calls (R4, R5, R6, R7, R8).....	89
6.4 R9 - Public address – incoming / outgoing.....	93
6.5 R10 - Positive link assurance.....	94
6.6 R11 - Negative link assurance.....	94
6.7 R12 – Loss of the network.....	95
6.8 R13 – PTT pressed.....	95
6.9 R14 – Uplink Busy.....	96
6.10 R15 – Failed action.....	97
Bibliography.....	98

Figures

Figure 1 — Areas of the DMI Display.....	13
Figure 2 — GSM-R Cab Radio Modes and States	23
Figure 3 — Basic Screen – Train Mode.....	24
Figure 4 — Basic Screen - Shunting Mode	25
Figure 5 — Adjusting brightness (Light sensor ‘inactive’)	41
Figure 6 — Adjusting brightness (Light sensor ‘active’)	42
Figure 7 — Self Test	44
Figure 8 — Language Selection.....	45
Figure 9 — Register Train Running Number	46
Figure 10 — Forced Deregistration	47
Figure 11 — Working position selection (function code).....	48
Figure 12 — Select mobile radio network.....	49
Figure 13 — Receiving a point-to-point call (before connection).....	50
Figure 14 — Receiving a point-to-point call (established).....	51
Figure 15 — Receiving a group call (before connection).....	52
Figure 16 — Receiving a group call (connected)	52
Figure 17 — Call primary controller	54
Figure 18 — Group call to other drivers in the same area	55
Figure 19 — Entering a group ID	56
Figure 20 — Choosing ‘group call’	57
Figure 21 — Receiving a Railway Emergency Call	58
Figure 22 — Outgoing Railway Emergency Call (established).....	60
Figure 23 — Call on hold	61
Figure 24 — On-going call plus waiting call	62
Figure 25 — On-going call plus held call	63
Figure 26 — Incoming REC with Call Waiting	64
Figure 27 — Forwarding a call to another number	65
Figure 28 — Activating forwarding.....	65
Figure 29 — Cancelling Forwarding a call to another number	67
Figure 30 — Call Forwarding unconditional activated	67
Figure 31 — Cancelling Forwarding a call to a hand-held portable.....	68
Figure 32 — Call Chief Conductor (Paging).....	69
Figure 33 — Public Address call.....	70
Figure 34 — Incoming Intercom call (established)	71
Figure 35 — Selecting other drivers on train.....	72
Figure 36 — Drivers connected in a multi-party call	73
Figure 37 — Intercom call from train staff to controller (established).....	75
Figure 38 — Calling a controller with a single keystroke.....	76

Figure 39 — Free-dial a number	77
Figure 40 — Select from Telephone Book	78
Figure 41 — Select from received calls list	79
Figure 42 — Loss of radio network.....	80
Figure 43 — Select shunting area.....	81
Figure 44 — Select Shunting group ID	82
Figure 45 — Alerting of a controller	84
Figure 46 — Receiving a text message	85
Figure 47 — R1 - Internal incoming call	88
Figure 48 — R2 - External incoming call	89
Figure 49 — R3 - Incoming emergency call	89
Figure 50 — R4 - Connection	90
Figure 51 — R5 - Line ringing.....	91
Figure 52 — R6 - Line busy.....	91
Figure 53 — R7 - Barred call.....	92
Figure 54 — R8 - Outgoing emergency call	93
Figure 55 — R9 - Public address.....	93
Figure 56 — R10 - Positive link assurance	94
Figure 57 — R11 - Negative link assurance	95
Figure 58 — R12 - Loss of the network	95
Figure 59 — R13 - PTT pressed.....	96
Figure 60 — R14 - Uplink busy	97
Figure 61 — R15_Failed_action	97

Tables

Table 1 — Description of functions used in each are.....	13
Table 2 — Description of functions associated with keys	14
Table 3 — TRD Symbols	17
Table 4 — TRD menu structure	26
Table 5 — TRD menu structure (Shunting).....	35
Table 6 — Menu structure (while in a call).....	37
Table 7 — Summary of sounds	86
Table 8 — R1 - Internal incoming call.....	88
Table 9 — R2 - External incoming call.....	88
Table 10 — R3 - Incoming emergency call.....	89
Table 11 — R4 - Connection	90
Table 12 — R5 - Line ringing	90
Table 13 — R6 - Line busy	91
Table 14 — R7 - Barred call	92

Table 15 — R8 - Outgoing emergency call.....	92
Table 16 — R9 - Public address – incoming / outgoing	93
Table 17 — R10 - Positive link assurance.....	94
Table 18 — R11 - Negative link assurance.....	94
Table 19 — R12 - Loss of the network.....	95
Table 20 — R13 - PTT pressed	96
Table 21 — R14 - Uplink busy	96
Table 22 — R15 - Failed action.....	97

European foreword

This document (CLC/TS 50459-2:2021) has been prepared by CLC/SC 9XA "Communication, signalling and processing systems", of Technical Committee CLC/TC 9X "Electrical and electronic applications for railways".

This document supersedes CLC/TS 50459-2:2015.

CLC/TS 50459-2:2021 includes the following significant technical changes with respect to CLC/TS 50459-2:2015:

- updated general principles for the presentation of ERTMS/ETCS/GSM-R information correlated with ERA document ERA_ERTMS_015560;
- updated ergonomic arrangements in line with EN 16186 series.

CLC/TS 50459 series consists of the following parts under the general title *Railway applications — Communication, signalling and processing systems — European Rail Traffic Management System — Driver-Machine Interface*:

- *Part 1: General principles for the presentation of ERTMS/ETCS/GSM-R information*;
- *Part 2: Ergonomic arrangements of GSM-R information* [the present document];
- *Part 3: Ergonomic arrangements of non ETCS information*.

Attention is drawn to the possibility that some of the elements of this document may be the subject of patent rights. CENELEC shall not be held responsible for identifying any or all such patent rights.

This document has been prepared under a mandate given to CENELEC by the European Commission and the European Free Trade Association.

Introduction

This document should be read in conjunction with ERA_ERTMS_015560, *ETCS Driver Machine Interface*, and the EN 16186 series, *Railway applications — Driver's cab*.

The CLC/TS 50459 series contains the ergonomic arrangements of information on the ERTMS/DMI Display (Control Command Display (CCD) and Train Radio Display (TRD)). Most items are illustrated with an example.

The reasons for defining the ergonomics of the DMI are as follows:

- achieving harmonized and coherent presentation for ERTMS/ETCS and NTC information;
- defining Driver-Machine Interface ergonomics that is compatible with agreed interoperable ERTMS specifications;
- to reduce the risk of incorrect operation by a driver;
- facilitating train operation with a unified ergonomics, hence reducing the cost of driver training;
- better understanding of the tasks to be performed;
- increasing speed and accuracy of driver actions.

1 Scope

This document describes from an ergonomic point of view how GSM-R information will be arranged and displayed. More specifically it covers information that is out of the scope of ERA document ERA_ERTMS_015560. This document describes more ergonomic details than currently provided by the GSM-R specifications.

This document defines the ergonomics for the Driver-Machine Interface (DMI) for the stand alone ERTMS/GSM-R Voice Radio Systems.

2 Normative references

The following documents are referred to in the text in such a way that some or all of their content constitutes requirements of this document. For dated references, only the edition cited applies. For undated references, the latest edition of the referenced document (including any amendments) applies.

EN 16186-2, *Railway applications - Driver's cab - Part 2: Integration of displays, controls and indicators*

EN 16186-3:2016+A1:2018, *Railway applications - Driver's cab - Part 3: Design of displays*

CLC/TS 50459-1:2021, *Railway applications — Communication, signalling and processing systems — European Rail Traffic Management System — Driver-Machine Interface - Part 1: General principles for the presentation of ERTMS/ETCS/GSM-R information*